


Download our software at [www.digitronicgas.com](http://www.digitronicgas.com) in the „Technical Support Service” area or click below:

[Digitronic Multipoint software](#)

Click for more info



	<a href="#">MP32</a>	<a href="#">MP48</a>	<a href="#">MP48 OBD</a>	<a href="#">MP6C</a>	<a href="#">2568D</a>
<b>Number of cylinders</b>	2/3/4	2/3/4	2/3/4	5/6	5/6/8
<b>Operating temperature</b>	-40 / +105 °C	-40 / +105 °C	-40 / +105 °C	-40 / +110 °C	-40 / +120 °C
<a href="#">Progressive petrol to gas switch (smooth transition)</a>	X	✓	✓	✓	✓
<a href="#">Split fuel option on engine load</a>	X	✓	✓	✓	✓
<b>Engine RPM reading from any ignition coil</b>	X	✓	✓	✓	✓
<a href="#">Gas temperature management</a>	X	✓	✓	✓	✓
<a href="#">Advanced Autocalibration (automatic Map adjusting)</a>	✓	✓	✓	✓	X
<a href="#">Petrol addition management</a>	X	✓	✓	✓	✓
<a href="#">Gas injectors enable/disable for diagnostic purpose</a>	X	✓	✓	✓	✓
<b>Lambda probe reading and emulation</b>	X	just reading one channel	one channel	two channels	two channels
<b>Linear Lambda probe emulation (UEGO)</b>	X	X	✓	✓	✓
<b>OBD II Adaptivity</b>	X	X	✓	✓	✓

